

Translations:Fusion welding of optical fibres/21/en

Before opening the cover, bring the smooove as close as possible to the fusion splicer, center it at the weld, making sure that the shrinkage will be on the fibre protection sheaths and not on the bare fibre. Position the smooove in the center of the furnace. The furnace is activated automatically if this function has been previously selected in the machine parameters, otherwise press the yellow resistance on the keyboard.