## Translations: Photometric Measurement/3/en

After switching on the device, check and set the measuring wavelength to 1490 nm, the wavelength of the downlink flow, if necessary.