

Translations:Changer le filtre d'une machine à laver/3/en

Unplug the washing machine from the wall outlet or turn off the power in your service panel.