Translations: Descale your Nespresso Pixie machine/18/en

Once the flow is complete, refill the tank with the used mixture.