Translations: Descale your Nespresso Pixie machine/21/en

Repeat Step 4, letting the entire descaling solution flow as before.